

Inflatable Bird Scarer

PA302883



Additional set up User manual

Before starting set-up, write out the following details:

1. **Current time:** _____
2. **Start time of operation:** _____
3. **Finish time of operation:** _____
4. **Action interval, i.e. 5 minutes = 5 or 20 minutes = 20:** _____
5. **Type of action you required:** _____

***Enter value 1 for FAN blow only**

***Enter value 2 for FAN and ALARM**

***Enter value 3 for FAN and LIGHT**

***Enter value 4 for FAN, LIGHT and ALARM**

6. Random or Irregular action interval: _____

***Enter 0 for regular set action intervals**

***Enter 1 for irregular action intervals**

Keep this sheet to hand, as you work through the initial cycle set up!

Once the battery has been connected correctly please follow the steps below to set up the time and actions as required

Please note a complete cycle of the set up must be completed for the memory to save your given values!

Action 1: Set the current time

Press the Selection & Enter button twice, use the up, and down arrows to adjust the hours

Press the Selection & Enter button again, use the up, and down arrows to adjust the minutes

Action 2: Set the time for operation to start

Press the Selection & Enter button once, use the up, and down arrows to adjust the hours

Press the Selection & Enter button again, use the up, and down arrows to adjust the minutes

Action 3: Set the time for operation to finish

Press the Selection & Enter button once, use the up, and down arrows to adjust the hours

Press the Selection & Enter button again, use the up, and down arrows to adjust the minutes

Action 4: Set the Action interval (5 = 5mins, 20 = 20 mins)

Press the Selection & Enter button once, use the up, and down arrows to adjust the action interval

Action 5: Adjust the type of action you require

Press the Selection & Enter button once, use the up, and down arrows to adjust the action type 1, 2, 3 or 4

Action 6: Adjust to regular or random intervals between actions

Press the Selection & Enter button once and use the up and down arrows to adjust the action type, 0 = regular, 1 = random

Action 7: Finish set up cycle

Press the Selection & Enter button once, then press the Start button – **Set up complete!**

To adjust the settings at any time, use the Selection & Enter button.

Due to the small internal control unit battery, all settings will remain for several weeks even if the main battery is disconnected.